

---

**Respirator Inspection Checklist**

---

<b>Face piece</b>	<input type="checkbox"/> No cracks, tears, or holes <input type="checkbox"/> No facemask distortion <input type="checkbox"/> No cracked or loose lenses or face shields
<b>Head straps</b>	<input type="checkbox"/> No breaks or tears <input type="checkbox"/> No broken buckles
<b>Valves</b>	<input type="checkbox"/> No residue or dirt, cracks, or tears in valve material
<b>Filters and cartridges</b>	<input type="checkbox"/> NIOSH approved <input type="checkbox"/> Gaskets seat properly <input type="checkbox"/> No cracks or dents in housing <input type="checkbox"/> Proper cartridge for hazards
<b>Air supply systems</b>	<input type="checkbox"/> Breathing-quality air is used <input type="checkbox"/> Supply hoses are in good condition <input type="checkbox"/> Hoses are properly connected <input type="checkbox"/> Settings on regulators and valves are correct

---

\*This checklist represents a general overview of respirator inspection requirements. Always refer to the manufacturer's user manual for more detailed information.